

# ACTUATOR RESET INSTRUCTIONS

These instructions are designed to walk you through the process of resetting the actuator systems used on your products. If there are any questions or problems with the process, please feel free to contact us.

To reset the actuators in your system, please unplug the simple UP/DOWN hand switch and plug in the programable hand switch (like the image in figure 1). The hand switch that was provided for your system is unique, please handle with care.

Please verify that the actuators are in the down or lowered position if possible.




Figure 1

## STEP 1

Once the programable hand switch is installed, verify that power is attached to the system. NOTE: Your system is installed with multiple control boxes that are “jumper’d” together. Because of this, each set of jumper’d control boxes need to be reset separately.

## STEP 2

To begin reset, hold the switch in both hands and PRESS and HOLD buttons 1,2 and UP for 5-8 seconds.

Once the system recognizes the RESET command, the display will show a “S 5” (Figure 2)




Figure 2

When this is displayed, TAP the DOWN arrow on the switch to display a “S 0” (Figure 3)

# ACTUATOR RESET INSTRUCTIONS




Figure 3

Once the switch displays the above-mentioned code, you might hear some “clicking” as the control box “resets”. Once the reset process is complete, the switch will display the following “E 61” (Figure 4)




Figure 4

## STEP 3

At this point, the system is reset and only requires a “re-initialize”. PRESS and HOLD the DOWN arrow for 10-15 seconds to re-initialize the system. Once complete, the switch should display “027” (Figure 5).




Figure 5

Once both sets of control boxes are reset, remove the programmable hand switch and install the switch that came with your system.

Verify that the system works with your original hand switch. All 4 actuating columns should now be in sync.

If the system does not function as described, please feel free to contact BUILT Systems via email or phone call.